

BM-1-F20F-M-RS1

FITTING MANUAL



Step 1

Remove the original diffuser.

(Photo 1)

Step 2

Use the original bumper mounting connections to mount the MaxtonDesign diffuser.

(Photos 2, 3, 4)

Step 3.1 (optional with step 3.2)

Fix the MaxtonDesign diffuser with the screws so that it does not fall out of the catches.

(Photos 5, 6, 7)

Step 3.2 (optional with step 3.1)

Using a heat gun, heat the catches and bend at an angle of 90° - be careful not to overheat the diffuser or bumper.

(Photos 10, 11, 12)

Step 4

Cut the original glare clips.

(Photo 8)

Step 5

Using screws, fix the reflective lights into the diffuser.

(Photo 9)

PHOTOS



For other fitting manuals please visit: maxtondesign.co.uk/fitting-manuals

