



# BONNET EXTENSION

## -INSTALLATION MANUAL-

### Disclaimer

These are fitting guidelines only and we highly recommend installations are undertaken by a professional. Maxton Design Ltd. can't be held liable for any damages or liabilities that may arise from following any guidelines given by the Company.

Vehicle modifications caused by the usage, abuse, or incorrect installation of Maxton Design Ltd. products might result in significant vehicle malfunction. Vehicle damage, major bodily injury, disability, and/or death are among the dangers. Any changes you make to your or someone else's car using Maxton Design Ltd. goods are your responsibility. Maxton Design Ltd. is not responsible for any changes made to automobiles as a result of the usage or abuse of its product and will not be held accountable. If you have little to no expertise installing any of the products sold via [maxtondesign.co.uk](http://maxtondesign.co.uk) website, professional installation is highly suggested.

Products are sold as-is, and we are not responsible for any damages or injuries sustained during installation or subsequent use of the vehicle. Because proper installation is crucial to our product's performance and longevity, please go through the documentation carefully and test your installation before resuming driving.

**COMPLETE SET CONTAINS:**

- Bonnet Extension
- Mounting Kit
- Mounting Manual



For more Installation Manuals visit  
[www.maxtondesign.co.uk/fitting-manuals](http://www.maxtondesign.co.uk/fitting-manuals)

**1 STEP 1**

Open the bonnet and clean thoroughly.



Please note these instructions are for guidance only. It is your responsibility to ensure the installation is undertaken in a safe and correct way. We strongly recommend you leave the installation to a qualified professional.

**2 STEP 2**

Place the bonnet extension upright and toward the windscreen.



**3 STEP 3**

Line up the bonnet and the bonnet extension.



**4 STEP 4**

Close the bonnet to ensure the bonnet extension is positioned correctly.



**5 STEP 5**

Once positioned correctly, degrease the area in which the bonnet extension will stick to.



**6 STEP 6**

Peel off the red tape around 3-4 cm.



**7 STEP 7**

Stick the bonnet extension to the bonnet carefully.



**8 STEP 8**

Once all the red tape is peeled off, press firmly to ensure the bonnet extension is secure.



# Thank you for choosing Maxton Design!

We hope our product will meet your expectations.  
Let us know if you have any questions.

+44 (0) 113 531 6574

[sales@maxtondesign.co.uk](mailto:sales@maxtondesign.co.uk)

[www.maxtondesign.co.uk](http://www.maxtondesign.co.uk)

