

### YOUR SET INCLUDES:

- Rear Center Splitter
- 8x bolt M6
- 8x washer M6
- 8x nut M6
- Installation Manual



### 1. CHECK FITTING:

Align the central rear splitter up against the rear bumper and between the exhaust holes (if applicable).



### 2. INSTALL SPLITTER:

Once positioned accordingly, drill holes through the bumper and central rear splitter.



### 3. FINISH INSTALLATION:

Insert the provided nuts into the drilled holes and add the washers and tighten the nuts.