

### YOUR SET INCLUDES:

- 1x Set Rear Center Splitters
- 8x bolt M6
- 8x washer M6
- 8x nut M6
- Installation Manual



#### 1. CHECK FITTING:

Align the rear side splitter up against the edge of the rear bumper near the wheels. Once aligned, fit the corners of the rear side splitters to the bumper.



#### 2. INSTALL SPLITTER:

Once positioned accordingly, drill holes through the bumper and rear splitters, and insert the provided screws and tighten the nuts.



3. Repeat steps 1 and 2 for the other side.